HD CAMERA SYSTEM



HD COLOR CAMERA + HD CAMERA ADAPTOR
HDC-500 HDCA-50/350



HD CAMERA OPERATIONAL CONTROL UNIT
HDCO-350

HD CAMERA ADAPTOR
HDCA-350

HD CAMERA SIGNAL DISTRIBUTOR
HDCD-50

HD CAMERA ADAPTOR
HDCA-50

HD CAMERA REMOTE CONTROL PANEL
HDCR-350



HD CAMERA SIGNAL PROCESSOR
HDCS-350



HD REMOTE CONTROL UNIT
HDCR-50



HD ELECTRONIC VIEWFINDER
HDVF-500

HD BLACK AND WHITE MONITOR
HDM-90



HD ELECTRONIC VIEWFINDER
HDVF-75



HD BLACK AND WHITE MONITOR
HDM-145



HD ELECTRONIC VIEWFINDER
HDVF-30



PAN TILT TABLE
HKCF-750



HD ELECTRONIC VIEWFINDER
HDVF-150



HD CAMERA SHOULDER PAD
HKCH-500

メンテナンスマニュアルの取扱いについて

HDC-500, HDCA-50, およびHDCD-50のメンテナンスマニュアルは，それぞれの製品に同梱されていますがHDCA-50に付属しているバインダーにそれらをファイルすることにより管理やメンテナンスが容易になります。
お手数でも機器購入後は，それぞれのメンテナンスマニュアルを，このバインダーにファイルしてお使い下さい。

Handling of Maintenance Manuals

Maintenance manuals for the HDC-500, HDCA-50 and HDCD-50 are supplied with each product. After purchasing the above products, place their manuals in the binder supplied with the HDCA-50. Using the binder to hold these manuals makes management and maintenance easier.

SYSTEM CONFIGURATION

HDC-500 CCU SYSTEM

※ これらのケーブルは、HDCC-2／5／50／100 と互換性があります。

※ These cables are compatible with the HDCC-2／5／50／100 cables.



HDC-500 STAND-ALONE SYSTEM



SYSTEM OVERALL BLOCK

HDC-500
HDCA-50
HDCD-50



HDC-500 STAND-ALONE SYSTEM BLOCK

B-WHOLE-STANDALONE-CHAIN.DGN